

BAY AND BOW WINDOWS

Any projected unit should be roofed, braced below each mullion and installed with cable support system. Cables should be oriented at least 45 degrees from horizontal and properly anchored to suitable structural building elements.

Bay and Bow windows are not a straightforward installation and due to the number of variables that could exist in the existing home's construction, there are no specific instructions available for a typical application. Most renovation applications are unique and generally speaking it is the experience of the contractor that determines the installation method that is appropriate for each type of application.